



Data, weights and dimensions are not binding for the manufacturer, who reserves the right to bring changes as he sees fit.

Spare parts: When ordering spare parts, please specify type of sprinkler and code number.

Code	Fig No.	No.	Description	Code	Fig No.	No.	Description	Code	Fig No.	No.	Description
	1	1	Sprinkler Body		22	1	Spacer		48	1	Spring
	2	1	Flange		23	1	Spacer		49	1	Screw
	2a	4	Connector Stud Bolt		24	1	Spacer		50	1	Nut
	2b	4	Nuts		25	2	Gasket		51	1	Pivot
	2c	1	Ring		26	1	Gasket		52	2	Bearing
	2d	1	O-Ring 3350		27	1	Gasket		53	1	Cap
	3	1	Internal Body		028	1	Complete Head		54	1	Washer
	3a	1	O-Ring 3600		28a	2	Screws		55	2	Screws
	4	1	Lock Ring		29	1	Pipe		56	2	Nuts
	4a	1	Screw		29a	1	Packing		57	2	Knob
	5	1	Spacer Ring		30	1	Washer		58	4	Plate For Counterweight
	6	1	O-Ring 3365		31	1	Ring		59	4	Screws
	8	1	U Ring		32	2	Spacer		60	4	Nuts
	9	1	Spheres Support		033	1	Complete Support		61	1	Cap
	10	60	Spheres		33	1	Support		62	1	Spring
	11	1	Brake		34	2	Screws		63	1	Pivot
	012	1	Complete Arm Support		35	2	Nuts		64	1	Pivot
	12	1	Arm Support		036	1	Complete Lever		65	1	Body
	12b	2	Bushing		36	1	Lever		066	1	Complete Clamp
	013	1	Complete Arm		37	1	Clamp		66	1	Clamp
	13	1	Arm		38	1	Screw		67	2	Screws
	14	1	Arm Support Pivot		39	3	Screws		67a	2	Nuts
	14a	2	Pivot Nut		40	3	Nuts		67b	2	Washers
	15	1	Spoon		41	1	Spring		68	2	Screws
	15a	2	Screws		42	2	Bearing		69	1	Ring
	15b	1	Screw		43	2	Nuts		70	4	Stud Bolt
	16	1	Nut		43a	2	Washers		70a	4	Nuts
	17	1	Nozzle Lock Ring		44	1	Shaft		70b	4	Washers
	18	4	Nozzle		45	1	Lever		071	1	Pivot
	19	1	Nozzle Packing		46	2	Screws		73	1	Nut
	20	2	Bearings		047	1	Complete Inversion Pivot		74	1	Spring
	21	2	Bearings		47	1	Pivot		75	2	Pin

