





a settori

circolare



Spare parts: When ordering spare parts, please specify type of sprinkler and code number.

Data, weights and dimensions are not binding for the manufacturer, who reserves the right to bring changes as he sees fit.

Code	Fig No.	Qty	Description	Code	Fig No.	Qty	Description	Code	Fig No.	Qty	Description
			PART CIRCLE	142726	26	1	Knob	142715kit	015	1	Complete Jet Breaker
142801kit	01	1	Sprinkler Body	140137a	27	1	Screw	142715	15	1	Jet Breaker
142702kit	02	1	Arm	142727a	27a	1	Nut	141816	16	1	Jet Breaker Screw
142702a	2a	1	Bush	142728	28	1	Secondary Nozzle	142726	26	1	Knob
142703	3	1	External Body	142729kit	029	1	Compleat Lock Ring	140137a	27	1	Screw
142704	4	1	Internal Body	142729	29	1	Secondary Jet Breaker	142727a	27a	1	Nut
142706	6	1	Spacer	142730	30	1	Cap Split Pin	142728	28	1	Secondary Nozzle
142707	7	1	Spring Cap	142734	34	1	Water Rectifier	142729kit	029	1	Complete Secondary Jet
142708	8	1	Arm Spring	142735	35	1	Jet Breaker Screw	142729	29	1	Secondary Jet Breaker
142709	9	1	Bush	142736	36	1	Spring	142730	30	1	Cap Split Pin
142710	10	1	Friction Spring	141837	37	1	Jet Breaker Spring	142734	34	1	Water Rectifier
142710a	10a	1	Friction Spring Cover	142738	38	2	Washer	142736	35	1	Jet Breaker Screw
142711	11	1	Vulk Washer					142736	36	1	Spring
142711a	11a	1	Teflon Washer					141837	37	1	Jet Breaker Spring
140318	12a	1	Teflon Washer					142738	38	2	Washer
142713	13	1	Vulk Washer	142701kit	01	1	Sprinkler Body				
142713a	13a	1	Rubber Washer	142702kit	02	1	Arm				
142714	14	3	Main Nozzle	142702a	2a	1	Bush				
142715kit	015	1	Complete Jetbreaker	142703	3	1	External Body				
142715	15	1	Jet Breaker	142704	4	1	Internal Body				
141816	16	1	Jet Breaker Screw	142706	6	1	Spacer				
142818kit	018	1	Complete Ring	142707	7	1	Spring Cap				
142818	18	2	Stopper Ring	142708	8	1	Arm Spring				
142819kit	019	1	Lever	142709	9	1	Bush				
142819a	19a	1	Pin For Lever	142710	10	1	Friction Spring				
142820kit	020	1	Hook Lever	142710a	10a	1	Friction Spring Cover				
142820a	20a	1	Pin For Lever	142711	11	1	Vulk Washer				
142821	21	1	Spring House	142711a	11a	1	Teflon Washer				
140319a	22	1	Inversion Spring	140318	12a	1	Teflon Washer				
142824	24	1	Inversion Lever Cover	142713	13	1	Vulk Washer				
142825kit	025	2	Inversion Screw	142713a	13a	1	Rubber Washer				
142825a	25a	2	Inversion Screw Spring	142714	14	3	Main Nozzle				