IB International Pty Ltd
PO Box 5481 Manly Qld 4179
Ph: 07 3348 8300 Fax: 07 3348 8900
Mob: 0408 379 619 Web: www.ibinternational.com.au

Junior

a settori



circolare



Spare parts: *When ordering spare parts, please specify type of sprinkler and code number.*

Data, weights and dimensions are not binding for the manufacturer, who reserves the right to bring changes as he sees fit.

Code	Fig No.	No.	Description	Code	Fig No.	No.	Description	Code	Fig No.	No.	Description
			Part Circle								
	01	1	Sprinkler Body								
	2	1	Arm								
	2a	1	Bush								
	3	1	External Body								
	4	1	Internal Body								
	6	1	Shaft Washer								
	7	1	Arm Spring Cap								
	8	1	Arm Spring								
	9	1	Spring Support								
	10	1	Friction Spring								
	11	2	Teflon Washer								
	13	1	Vulk Washer								
	14	1	Rubber Washer								
	17	1	Jet Breaker Spring								
	17a	1	Jet Breaker Screw								
	18	2	Inversion Ring								
	020	1	Primary Lever								
	021	1	Secondary Lever								
	22	1	Spring House								
	23	1	Inversion Spring								
	25	1	Inversion Lever Cover								
	29	1	Pin For Lever								
	30	1	Pin For Lever								
	31	1	Cap Split Pin								
	44	1	Or 121								
	46	1	Nozzle								