IB International Pty Ltd
PO Box 5481 Manly Qld 4179
Ph: 07 3348 8300 Fax: 07 3348 8900
Mob: 0408 379 619 Web: www.ibinternational.com.au

Duplex

Part Circle



Data, weights and dimensions are not binding for the manufacturer, who reserves the right to bring changes as he sees fit.

Spare parts: *When ordering spare parts, please specify type of sprinkler and code number.*

Code	Fig No.	Qty	Description	Code	Fig No.	Qty	Description	Code	Fig No.	Qty	Description
142301kit	01	1	Sprinkler Body	142321	21	1	Spring House				
142302kit	02	1	Arm	140319a	22	1	Inversion Spring				
142203	3	1	External Body	142324	24	1	Inversion Lever Cover				
142204kit	04	1	Internal Body	142325kit	025	2	Inversion Screw				
142306	6	1	Spacer	142325a	25a	2	Inversion Screw Spring				
142307	7	1	Arm Central Ring	142226	26	1	Wedge				
142307a	7a	1	Elastic Pin	142226a	26a	1	Wedge Shaft				
142309kit	09	1	Arm Lateral Ring	142226b	26b	1	Locking Nut				
142210	10	1	Friction Spring	142227	27	1	Screw				
142210a	10a	1	Friction Spring Cover	142227a	27a	1	Nut				
142211	11	2	Vulk Washer	142228	28	1	Pipe-Head				
142211a	11a	2	Teflon Washer	142229	29	1	Secondary Nozzle				
142212	12	1	Inox Washer	142229a	29a	1	Packing For Nozzle				
142312a	12a	1	Washer	142330kit	030	1	Bearing Cover				
142313	13	1	Washer	142231	31	1	Water Rectifier				
142213a	13a	1	Rubber Washer	142233	33	1	Principal Pipe				
142214	14	5	Main Nozzle	142334	34	2	Screw				
142214a	14a	1	Nozzle O-Ring	140353	35	1	Arm Grover				
142215kit	015	1	Complete Principal Jet	142336	36	2	Bush				
142215	15	1	Jet Breaker	142338	38	2	Washer				
141816	16	1	Jet Breaker Screw	142339	39	1	Spring				
141837	16a	1	Jet Breaker Spring								
141437	17	1	Nozzle Lock Ring								
142318kit	018	1	Complete Stopper Ring								
142318	18	2	Stopper Ring								
142319kit	019	1	Complete Lever								
142319a	19a	1	Pin For Lever								
142320kit	020	1	Complete Hook Lever								
142320a	20a	1	Pin For Hook Lever								